



**BarnesBrinkcraft**  
Serving the Norfolk Broads since 1967

WELCOME TO  
CONCERTO 2

# BOAT INFORMATION

THE BOATYARDS NAME IS	BARNES BRINKCRAFT in WROXHAM
BOATYARDS TELEPHONE NUMBER	01603 782625 – 8am to 5pm
AFTER HOURS TELEPHONE NUMBER	01603 782625 – option one
THIS BOAT IS NAMED	CONCERTO 2 (ELITE CLASS)
TURNAROUND DAYS	SAT/TUES
LENGTH OF BOAT	35FT (10.67M)
WIDTH	12FT (3.66M)
STEERING	DUAL STEERING
BRIDGE CLEARANCE HEIGHT WITH SCREENS LOWERED	8FT (2.44M)
BRIDGE CLEARANCE	WILL NOT PASS UNDER WROXHAM BRIDGE, POTTER HEIGHAM BRIDGE OR BECCLES OLD BRIDGE
BERTHS	3 DOUBLES IN <u>2 CABINS</u> & SALOON
BED SIZES	SEE BOAT LAYOUT

<b>HOW TO MAKE UP BED IN SALOON</b>	<b>MOVE TABLE, PULL BOTTOM OF SOFA OUT PLACE CUSHIONS ON TOP</b>
<b>BATHROOM</b>	<b>1 BATHROOM &amp; 1 ENSUITE WITH TOILET/SHOWER</b>
<b>HOW TO DRAIN SHOWER</b>	<b>FRONT SHOWER - SWITCH ON SIDE WALL  BACK SHOWER - BUTTON IN SHOWER CUBICLE</b>
<b>COOKING FACILITIES</b>	<b>ELECTRIC 2 RING MICRO COMBI OVEN MICROWAVE</b>
<b>FRIDGE/FREEZER</b>	<b>UNDER COUNTER FRIDGE WITH SMALL FREEZER BOX</b>
<b>BOW THRUSTER?</b>	<b>YES</b>
<b>ELECTRIC ANCHOR WINCH?</b>	<b>YES</b>
<b>POWER</b>	<b>240v POWER  SHORE INVERTOR 5000w</b>
<b>HEATING</b>	<b>HEATER RUNS OFF THE DIESEL FANS RUN OFF THE ELECTRIC  INSTRUCTIONS INCLUDED IN YOUR MANUAL</b>
<b>NUMBER OF POWER SOCKETS</b>	<b>6</b>
<b>WIFI</b>	<b>YES ( LIMITED )</b>

<b>THE MAXIMUM NUMBER OF BERTHS FOR THIS BOAT IS</b>	<p style="text-align: center;"><b>6 (4+2)</b></p>
<b>ADDITIONAL INFORMATION</b>	<ul style="list-style-type: none"> <li>• SEPARATE SHOWER CUBICLE &amp; FRONT WET ROOM</li> <li>• DVD PLAYER</li> <li>• HAIR DRYER</li> <li>• <b>LICENSED FOR 9 PERSONS MAX IF USED AS A DAY BOAT DURING YOUR HIRE</b></li> </ul>

## WIFI connection

To connect to your onboard wifi, you will need to go into your wifi settings and the name of your boat **or** brinkcraft guest will appear.

Enter the information from the voucher you have been given, once this has been entered, you will need to accept the terms and conditions and fill in a few details.

Once the voucher runs out you can purchase more data via the online portal. (prices online)

SWITCH UP FOR AIR CIRCULATION (NOT RECOMMENDED)



THERMOSTAT CONTROL

SWITCH DOWN FOR HEATER

## How to work your heating system

Switch heating on as shown on opposite page.

Allow 10 minutes for the system to start and heat to come through.

If heater does not start after 10 minutes it may be that the temperature in the boat is higher than set.

Set the temperature to maximum, and check the boat batteries are charged. If necessary start engine to charge batteries.

If this does not work please call the on call engineer. 01603 782625 option 3

When heater is switched off it will continue to run for up to 10 minutes while it cools itself down.

# Concerto

Fri/Mon (1+6) or Sat/Tues (2, 3, 4 +5) start – 3 doubles in 2 cabins & saloon - 2 toilets/showers in 1 bathroom & 1 en-suite

