



**BarnesBrinkcraft**  
Serving the Norfolk Broads since 1967

WELCOME TO  
RHAPSODY 1

# BOAT INFORMATION

THE BOATYARDS NAME IS	BARNES BRINKCRAFT in WROXHAM
BOATYARDS TELEPHONE NUMBER	01603 782625 – 8am to 5pm
AFTER HOURS TELEPHONE NUMBER	01603 782625 – option one
THIS BOAT IS NAMED	RHAPSODY 1 (ELITE CLASS)
TURNAROUND DAYS	SAT/TUES
LENGTH OF BOAT	44FT (13.41M)
WIDTH	12FT (3.66M)
STEERING	DUAL
BRIDGE CLEARANCE HEIGHT WITH SCREENS UP	N/A
BRIDGE CLEARANCE HEIGHT WITH SCREENS LOWERED	8FT 2IN (2.49M) SCREENS DOWN & SIDES DOWN
BRIDGE CLEARANCE	WILL NOT PASS UNDER WROXHAM BRIDGE, POTTER HEIGHAM BRIDGE, OR BECCLES OLD BRIDGE
BERTHS	4 DOUBLES IN <u>3 CABINS</u> & SALOON

<b>BED SIZES</b>	<b>SEE BOAT LAYOUT</b>
<b>HOW TO MAKE UP SALOON BED</b>	<b>LOWER TABLE LAY ACROSS SHAPED CUSHIONS STORED IN BOAT</b>
<b>BATHROOM</b>	<b>1 WET ROOM &amp; 1 ENSUITE WITH TOILET/SHOWER</b>
<b>HOW TO DRAIN SHOWER</b>	<b>WET ROOM - SWITCH ON BATHROOM PANEL SEPARATE SHOWER - SELF DRAINING</b>
<b>COOKING FACILITIES</b>	<b>ELECTRIC 4 RING INDUCTOR OVEN &amp; GRILL MICROWAVE</b>
<b>FRIDGE/FREEZER</b>	<b>UNDER COUNTER FRIDGE WITH FREEZER BOX</b>
<b>BOW THRUSTER?</b>	<b>YES</b>
<b>ELECTRIC ANCHOR WINCH?</b>	<b>YES</b>
<b>POWER</b>	<b>240v POWER  SHORE INVERTER 5000w GENERATOR &amp; SOLAR</b>
<b>HEATER</b>	<b>HEATER RUNS OFF THE DIESEL FANS RUN OFF THE ELECTRIC  INSTRUCTIONS INCLUDED IN YOUR MANUAL</b>
<b>NUMBER OF POWER SOCKETS</b>	<b>8</b>

WIFI	YES ( LIMITED )
THE MAXIMUM NUMBER OF BERTHS FOR THIS BOAT IS	8 (6+2)
ADDITIONAL INFORMATION	<ul style="list-style-type: none"> <li>• DVD PLAYER</li> <li>• HAIR DRYER</li> <li>• 4 COLOUR TVS</li> <li>• WINE COOLER</li> <li>• ELECTRIC HYBRID WITH BOW &amp; STERN THRUSTER</li> <li>• INTEGRATED PLATFORM FOR EASY ACCESS</li> <li>• <b>LICENSED FOR 11 PERSONS MAX IF USED AS A DAY BOAT DURING YOUR HIRE</b></li> </ul>

## WIFI CONNECTION

To connect to your onboard wifi, you will need to go into your wifi settings and the name of your boat **OR** Brinkcraft guest will appear.

Enter the information from the voucher you have been given, once this has been entered, you will need to accept the terms and conditions and fill in a few details.

Once the voucher runs out you can purchase more data via the online portal. (prices online)

## How to work your heating system

Switch heating on via control panel in saloon.

Allow 10 minutes for the system to start and heat to come through.

If heater does not start after 10 minutes it may be that the temperature in the boat is higher than set.

Set the thermostat to maximum, and check the boat batteries are charged. If necessary start engine to charge batteries.

If this does not work please call the on call engineer. 01603 782625 option 3

When heater is switched off it will continue to run for up to 10 minutes while it cools itself down.

# Rhapsody

- Sat/Tues start - 4 doubles in 3 cabins & saloon - 2 toilets/showers in 1 wet room & 1 en-suite

6ft 6in x 4ft 6in at top  
(4ft wide at base, slightly curved)

7ft 8in x 4ft 4in at top  
(5ft of length before the curve)  
(2ft 10in at the base)



6ft x 4ft

7ft (outside edge) x 3ft 9in  
(6ft 10in inside length)