



BarnesBrinkcraft
Serving the Norfolk Broads since 1967


**WELCOME TO
HARMONY 2**

THE BOATYARDS NAME IS	BARNES BRINKCRAFT RIVERSIDE ROAD WROXHAM NR12 8UD
BOATYARDS TELEPHONE NUMBER	01603 782625 – 8am to 5pm
AFTER HOURS TELEPHONE NUMBER	01603 782625
THIS BOAT IS NAMED	HARMONY 2

TURNAROUND DAYS	SAT/TUES
LENGTH OF BOAT	44FT (13.4M)
WIDTH	12FT (3.66M)
STEERING	SINGLE
BRIDGE CLEARANCE HEIGHT WITH CANOPY AND SCREENS UP	8FT (2.43M)
BRIDGE CLEARANCE HEIGHT WITH CANOPY AND SCREENS LOWERED	7FT (2.14M)
BRIDGE CLEARANCE	<p>WILL NOT PASS UNDER POTTER HEIGHAM BRIDGE WILL NOT PASS UNDER WROXHAM BRIDGE</p> <p>Weather conditions and tide affect river levels so caution should be exercised at all bridges and please check the bridge clearance gauge carefully.</p>
BERTHS	4 DOUBLES IN 4 CABINS
BED SIZES	SEE BOAT LAYOUT
BATHROOM	1 BATHROOM & 2 ENSUITE WITH TOILET/SHOWER
HOW TO DRAIN SHOWER	FRONT SHOWER - BUTTON ON BACK WALL MIDDLE SHOWER - BUTTON NEXT TO TOILET FLUSH BACK SHOWER - BUTTON NEXT TO TOILET FLUSH
COOKING FACILITIES	ELECTRIC 2 RING HOB, LARGE OVEN WITH GRILL AND MICROWAVE
FRIDGE/FREEZER	UNDER CABINET FRIDGE WITH FREEZER BOX
BOW THRUSTER?	YES
ELECTRIC ANCHOR WINCH?	YES
POWER	240V POWER FROM GENERATOR, INVERTOR & SHORE POWER SHORE INVERTER 3000w GEN
HEATER	HEATER RUNS OFF THE DIESEL FANS RUN OFF THE ELECTRIC INSTRUCTIONS INCLUDED IN YOUR MANUAL
NUMBER OF POWER SOCKETS	6 – 2 IN GALLEY WITH 2 USB PORTS, 2 IN FORWARD CABINS, 1 IN STERN CABIN AND 1 IN MID CABIN
WIFI	YES
THE MAXIMUM NUMBER OF BERTHS FOR THIS BOAT IS	8

HEATING CONTROL

YOUR BOAT IS EQUIPPED WITH THIS HEATING CONTROL



HOW TO WORK YOUR HEATING SYSTEM

SWITCH HEATING ON AS SHOWN ABOVE.

ALLOW 10 MINUTES FOR THE SYSTEM TO START AND HEAT TO COME THROUGH.

IF HEATER DOES NOT START AFTER 10 MINUTES IT MAY BE THAT THE TEMPERATURE IN THE BOAT IS HIGHER THAN SET.


SET THE TEMPERATURE TO MAXIMUM AND CHECK THE BOAT BATTERIES ARE CHARGED. IF NECESSARY START ENGINE TO CHARGE BATTERIES.

IF THIS DOES NOT WORK PLEASE CALL THE ON CALL ENGINEER. 01603 782625

WHEN HEATER IS SWITCHED OFF IT WILL CONTINUE TO RUN FOR UP TO 10 MINUTES WHILE IT COOLS ITSELF DOWN.

Harmony

Fri/Mon (1) & Sat/Tues (2+3) start - 4 doubles in 4 cabins - 3 toilets/showers in 1 bathroom & 2 ensuite



WIFI

This boat is connected to our new unlimited WiFi. To connect to your onboard WiFi you will need to go into your device's WiFi settings and select: "BarnesBrinkcraft WiFi"

You should then be taken to a login page that asks you to accept the Terms and Conditions


Throttle Controls

This boat has lower steering position. Your boat will have the throttle controls pictured below.

The throttle controls the speed of the boat. The further forward you push it the faster it will go and the further back you pull it the faster it will go in reverse.

How to start your boat:

1. check your throttle is in neutral. If your boat has dual control check both throttles are in neutral. You can check this by making sure both the small triangle and notch on the inside on the throttle are lined up.



2. Put keys in ignition and turn.
3. If there is a start button next the ignition, push it to start the boat and both engine lights will come on. (The top two lights) If they don't come on it mean the boat is probably not in neutral. Check this at try again.

4. Press 'Command' on the controls you will

be using (either upper or lower helm). You'll need to push the button for 1 second, and you will see the blue light come on above the command button.

5. The 'Warm/Sync' light will now be flashing. This means the gear control is disengaged.

If you push the throttle forward it will rev the engine without moving.

6. Push the 'Warm/Sync' button (for 1 second) and the gear will be engaged. You can now drive the boat with the throttle.
7. Before untying the and leaving the moorings test the throttle is working in forward and reverse by gently pushing the throttle slightly in both directions. Once you're confident the boat is responding to the throttle you can untie from the moorings and head off.



If you are not sure how to operate the boat or have any other concerns, please call our team (01603 782625).