



BarnesBrinkcraft
Serving the Norfolk Broads since 1967

**WELCOME TO
REGAL STAR**

THE BOATYARDS NAME IS	BARNES BRINKCRAFT RIVERSIDE ROAD WROXHAM NR12 8UD
BOATYARDS TELEPHONE NUMBER	01603 782625 – 8am to 5pm
AFTER HOURS TELEPHONE NUMBER	01603 782625
THIS BOAT IS NAMED	REGAL STAR (MID-RANGE CLASS)


BOAT INFORMATION

TURNAROUND DAYS	SAT/TUES
LENGTH OF BOAT	30FT 6IN (9.30M)
WIDTH	11FT (3.35M)
STEERING	SINGLE
BRIDGE CLEARANCE HEIGHT WITH SCREENS UP	8FT 8IN (2.64M)
BRIDGE CLEARANCE HEIGHT WITH SCREENS LOWERED	N/A
BRIDGE CLEARANCE	<p style="text-align: center;">WILL NOT PASS UNDER WROXHAM BRIDGE. POTTER HEIGHAM BRIDGE OR BECCLES OLD BRIDGE</p> <p style="color: red; text-align: center;">Weather conditions and tide affect river levels so caution should be exercised at all bridges and please check the bridge clearance gauge carefully.</p>
BERTHS	<p style="text-align: center;">2 DOUBLES OR 1 DOUBLE & 2 SINGLES IN <u>1 CABIN</u> & SALOON</p>
BED SIZES	SEE BOAT LAYOUT
BATHROOM	<p style="text-align: center;">1 BATHROOM WITH TOILET/SHOWER</p>
HOW TO DRAIN SHOWER	SWITCH ON SIDE WALL
COOKING FACILITIES	<p style="text-align: center;">INDUCTION 2 RING HOB MICROWAVE COMBI OVEN</p>
FRIDGE/FREEZER	SMALL FRIDGE – NO ICE BOX
BOW THRUSTER?	YES
ELECTRIC ANCHOR WINCH?	NO
POWER	<p style="text-align: center;">240v POWER</p> <p style="text-align: center;">SHORE INVERTER 5000w</p>
HEATER	<p style="text-align: center;">SWITCH ON DASHBOARD - THERMOSTATS IN FRONT CABIN & SALOON</p> <p style="text-align: center;">HEATER RUNS OFF THE DIESEL FANS RUN OFF THE ELECTRIC</p> <p style="text-align: center;">INSTRUCTIONS INCLUDED IN YOUR MANUAL</p>
NUMBER OF POWER SOCKETS	4 – 2 IN SALOON, 1 IN GALLEY, 1 IN FOREPEAK
WIFI	NO
THE MAXIMUM NUMBER OF BERTHS FOR THIS BOAT IS	<p style="text-align: center;">4 (2+2)</p>
ADDITIONAL INFORMATION	<ul style="list-style-type: none"> • HAIR DRYER • WELL-EQUIPPED ALL WEATHER CRAFT • REAR OUTSIDE SEATING • AIRY SALOON WITH SUN ROOF • LICENSED FOR 7 PERSONS MAX IF USED AS A DAY BOAT DURING YOUR HIRE

Regal Star

- Sat/Tues start - 2 doubles or 1 double & 2 singles in 1 cabin & saloon - 1 toilet/shower in 1 bathroom -

2



THROTTLE CONTROL FOR YOUR BOAT

(Regal Star)

The throttle control for your boat is pictured below.

The boat is out of gear (in neutral) when the lever is in the reclined 10 o'clock position (in line with top of dashboard - see below).



Push the lever up and forwards to engage forward gear. The further forwards you push it, the faster the boat will go.

Pull the lever backwards past neutral to reverse or slow down. Again, the further you pull the throttle back, the faster the boat will go in reverse.

To disengage the gear junction while the boat is out of gear or in the neutral position, pull the base of the throttle lever out. You can then move the lever

forwards to rev the engine for cold starting, battery charging or heating the water. Push the throttle lever back in to re-engage the gear function, to drive the boat.

Always keep your speed below the speed limit; slowing down a little can make a big saving on fuel use. As always, if you are not sure how to operate the boat or have any other concerns, please call our team (01603 782625).

HEATING CONTROL

YOUR BOAT IS EQUIPPED WITH THIS HEATING CONTROL

HOW TO WORK YOUR HEATING SYSTEM

SWITCH HEATING ON.

ALLOW 10 MINUTES FOR THE SYSTEM TO START AND HEAT TO COME THROUGH.

IF HEATER DOES NOT START AFTER 10 MINUTES IT MAY BE THAT THE TEMPERATURE IN THE BOAT IS HIGHER THAN SET.

SET THE TEMPERATURE TO MAXIMUM AND CHECK THE BOAT BATTERIES ARE CHARGED. IF NECESSARY START ENGINE TO CHARGE BATTERIES.

IF THIS DOES NOT WORK PLEASE CALL THE ON CALL ENGINEER. 01603 782625

WHEN HEATER IS SWITCHED OFF IT WILL CONTINUE TO RUN FOR UP TO 10 MINUTES WHILE IT COOLS ITSELF DOWN.

